

NIGHTSTAND INSTRUCTIONS

If you need the door to open in the opposite direction, you can unscrew the indicated screws, the magnet and screw them back at the opposite side.

